

1. USING A SMALL SCREWDRIVER OR NAIL, TAP OUT THE PIN (KNURLED END FIRST)



N.B.  
THE PLAIN END OF THE PINS ARE ALWAYS INSERTED FIRST FROM THE RIGHT HAND SIDE ALWAYS KNOCK OUT FROM THE LEFT HAND SIDE SO THAT THE KNURLED SECTION COMES OUT FIRST

2. IF NECESSARY ONCE THE END OF THE PIN IS PRUTRUDING USE PILERS TO PULL OUT



3. REMOVE ROCKER AND SPRING



4. PULL SHARPLY TO REMOVE BOTTOM HANDLE



5. REMOVE 2 HALF SHIMS



6. SLIDE OFF LOCKING COLLAR



*PARTS:*  
BOTTOM SHIM  
TOP SHIM  
LOCKING COLLAR  
ROCKER  
SPRING  
KNURLED PIN

**REASSEMBLE IN REVERSE ORDER**

1. SLIDE LOCKING COLLAR ONTO HANDLE



2. LOCATE BOTTOM SHIM ENSURING LUGS FIT INTO HOLES IN HANDLE. SIMILARLY LOCATE TOP SHIM



3. SLIDE BOTTOM HANDLE OVER & CONNECT WITH LOCKING COLLAR



4. INSERT SPRING



5. INSERT ROCKER ENSURING BRASS LUG FITS TO HOLE



6. INSERT PIN FROM RIGHT HAND SIDE WITH KNURLED SECTION LAST.



TAP HOME WITH HAMMER.

TAP HOME WITH HAMMER.