

Assembling DP556:

- 1) When assembling, first place the two handles adjacent to each other to ensure they are the right way round, there is a left and a right.
- 2) The flat side of each of the long parts of the handle body should be facing each other.
- 3) Put the thicker of the three bolts supplied through the hole in the middle of the two handles, making sure to use the plastic and steel washers supplied.
- 4) Join the handles at this axis making sure the bends of the handles are facing inward towards each other and tighten the nut.
- 5) Place the paddles on the handle body ends, ensuring they are also facing inward (the ribbed edge will be on the outside).
- 6) Align the holes in the paddle collar and the holes on the end of the handle body.
- 7) Put the two remaining bolts through, ensuring that the bolt head is sitting on the recessed side of the paddle collar. This will ensure a proper fit. Tighten both bolts.

